

Modifying Chrome Cable clamps for Volusia

These can be bought at AutoZone and maybe other Auto Part stores. I found them (with Garym262's tip) in the Performance Parts (rice racer) Section for about \$10.

You get:

2 each of 2-cable clamps,
3-cable clamps, and 4-cable
clamps. You also get a free
Allen Wrench! Wooo Hooo!
Not!



Out of the box, only the 2-cable clamps will work. You will need a dremel to mod the others to fit well.

Go ahead and put the 2
2-cable clamps on the throttle
cables. They fit great. This will
give you an idea why the other,
fatter, cables won't fit. The bolt
that holds the two side together
is short. You could by pass the
mod and get longer ones, but
what's the fun in that?



The next few pages detail how to mod the others to fit

What you'll need to do is on the 3-cable clamps, dremel out the "teeth" between the two separate cable slots on the 2-cable side. Do this for both sides of the clamp.

This allows them to easily fit the switch cable on the left side.



I also carefully dremeled out the one cable side to allow a cleaner fit on the clutch cable. I expanded the hole closer towards where the bolt goes.



Both go on these cables, close to the grip, and close to the triple tree.



Now, for the right side Switch and Brake line.

Dremel out the “teeth” between the 2-cable slots, on both sides of each clamp.

This first one goes right below the “banjo”



For the one closer to the triple tree, you have a choice. When you put it on, it won't fit snug over the brake line because of the added “sleeve”. You need to carefully remove a little extra material on one “end” (both pieces of clamp) to allow the brake line to fit better.

Be Careful, the plastic is already thin, you just need to remove a little bit to compensate for the sleeve.



You're done! Total Mod time: about 45 minutes.

