

Home Depot Chrome Choke Knob

1. Remove the tool box cover for more room



2. With a dremel or utility knife, cut both sides of the black rubber knob from front to back.





3. Peel back the knob and remove it.



4. Using a dremel or other item, remove the white plastic on the end of the metal shaft.



5. Starting with a 10/32 die, carefully thread the shaft. Then use a 8/32 to finish the thread. It will be hard to start, so work slowly.
6. Be careful not to rotate the shaft, or it will “lock” inside the casing. If you do “lock” the cable, remove the back “collar” at the base of the shaft. Now, using vicegrips, grab the cable with one pair, and the base of the shaft with another and rotate the shaft counter-clockwise until you feel the cable “pop” into place.



7. Once the shaft is threaded, place the block “collar” back on (if you removed it to unlock the cable).



8. Now, place the knob on the shaft, and you're done!

