

## ***Installing Kuryakyn Grips w/o stock end weights***

1. Remove left grip weight, by loosening the end weight, wiggle it out.
2. run a coat hanger under the rubber for the grip itself, rotating it around until the grip is broken free from the glue. Work the grip off. Slide off the chrome ring.
3. remove the end weight for the right side by loosening the screw, and wiggling it out.
4. remove the screws holding the rightside switch assembly together. Gently pry it open. You may need to loosen the throttle cables to get some "play" to allow you to unhook the throttle cables from the stock throttle sleeve. Once the cables are unhooked, slide the grip and sleeve off.
5. slide the new throttle grip on.
6. reconnect the throttle cables.
7. reassemble the switch assembly.
8. Tighten the throttle cables until you have just a little "free play" in the throttle.
9. Install the end piece on the grip (if supplied).
10. Clean the leftover glue off the left side bar.
11. Slide the left grip on, checking for fit and position.
12. Once happy, slide the grip off.
13. The next steps will need to be done fairly quickly and CORRECTLY!
14. Open the grip glue, and carefully place some near the end of the bar in various places.
15. Quickly slide the grip on, in one smooth motion, and rotate to the proper placement. Once you stop moving it, it will QUICKLY glue into place!
16. install the end piece.
17. Enjoy!